



Strike-Rite # SR-ASA-001 Installation Instructions

Strike-Rite # SR-ASA-001 Installation instructions

Contents: 1-ASA strike plate, 1-Adjusting knob, 2-mounting screws, 1-Setscrew and 1-Allen wrench.

- Make sure the setscrew is installed (but not tightened) in the hole in the front of the strike plate.
- Turn the adjusting knob in (clockwise) all the way but not tight.
- Install strike plate, secure with 2 mounting screws into ASA metal frame.
- Close door, check fit and adjust as described below.

If door is loose, rotate Adjusting knob out. Adjust until door fits tight with a small clearance. Look close and verify that the door plunger is fully into the latch opening and the dead latch feature is engaged resting on the adjusting knob and not inside the strike opening. Open and close the door a few times to ensure the proper fit. When proper fit is achieved, tighten the setscrew with the Allen wrench. Verify the setscrew is secure by trying to rotate the adjustment knob.

If you need any assistance with the Strike-Rite plate, contact SR Products at 352-503-6826
US Patent# 9,493,964

